

Aprilia RST 1000 Futura

- = Connector 1
- = Connector 2
- = Connector 3

- 15A Secondary Fuses**
- A - Headlight (high/low beam), Dashboard
 - B - Fuel Pump
 - C - Parking Lights, Rear Stoplight, Horn, Direction Indicators
 - D - Start, Safety Logic
 - E - Free, Accessory Outlet

